



Integrus version 4.40



BOSCH

en Release Notes

Table of Contents

1	History	3
2	Information not mentioned in the manual.....	3
2.1	Dante support.....	3
3	Known issues.....	4
3.1	Distorted audio on receivers when source is received as Dante and DICENTIS	4
3.2	INT-TXO restarts after several Operation mode switches	4
3.3	frontpanel LED	4
3.4	Demonstator shows 500 Internal Server error	4
3.5	INT-TXO remains in static IP when downgraded to 6.11 (or lower) software.....	4

1 History

Release	Release Date	Release Comments
4.40.39678	2024-11-06	<p>This release is part of</p> <ul style="list-style-type: none"> • DICENTIS 6.30.13 • DICENTIS 6.22.56 • Standalone installer 2.10.194 <p>Fixes and improvements:</p> <ul style="list-style-type: none"> • Fixed issue where receiver does not show antenna symbol and audio is lost. • Fixed issue that microphone on/off on Interpreter desk causes short mute on the floor audio. • Fixed issue with pilot tone. The Pilot tone is used to calibrate the cable length to align the audio levels. • Improved user interface, Audio configuration and Carrier management page are hidden when the operation mode is Slave. • Improved user interface, dashboard shows information when no radiators are detected. • Improved user interface, RSTP state is reported and system information is re-organized. • Improved user interface, removed Test tone button for user with Operator rights. • Improved user interface, removed reboot button for user with Operator rights. • Improved user interface, Test tone reboot button is removed when auxiliary mode is active. • Improved user interface, reboot button is removed when auxiliary mode is active. • Improved user interface, added information to logging options. • Improved licensing, added validity check for the activation ID to prevent creating invalid licenses. • Improved translations.
4.30.38858	2024-07-30	<p>This release is part of</p> <ul style="list-style-type: none"> • DICENTIS 6.20.24 and 6.21.34 • Standalone installer 2.00.149 <p>Added functionality:</p> <ul style="list-style-type: none"> • New web based user interface for configuration. • Integrus can be used with Dante sources in Manually controlled mode. • Integrus can be used with a combination of DICENTIS and Dante sources in Manually controlled mode. • Analog Aux input can be routed to all transmitted channels via contact input.
4.20.33007	2023-02-11	<p>Initial version:</p> <ul style="list-style-type: none"> • INT-TXO is supported by DICENTIS 4.20.33007

2 Information not mentioned in the manual

2.1 Dante support

When the INT-TXO is in manually controlled mode, then both DICENTIS as Dante sources can be connected. The Dante sources can be unicast or multicast and 1 flow per stream.

Dante glitch free is not supported.

The INT-TXO can also be enrolled in the Dante Domain Manager when it is in Manually controlled mode.

Note: un-enrol the INT-TXO from the Dante Domain Manager before setting the INT-TXO back to DICENTIS controlled mode. Not doing so can cause unpredictable behavior.

3 Known issues

3.1 Distorted audio on receivers when source is received as Dante and DICENTIS

Issue:

When you have a setup where languages are provided by DICENTIS interpreter desks and Dante sources, then the receiver can have distorted audio if the INT-TXO inputs are linked to the same audio source, but 1 being the Dante and another being the DICENTIS source.

Workaround:

Use the DICENTIS outputs as inputs for all sources. Because the INT-TXO cannot receive the same audio/language coming from both the Dante source as the DICENTIS source.

3.2 INT-TXO restarts after several Operation mode switches

Issue:

After switching the Operation mode of the INT-TXO several times between DICENTIS controlled and Manually controlled, the INT-TXO will restart for optimum performance.

Workaround:

This restart is done automatically, so no action required.

3.3 frontpanel LED

Issue:

After powering up, booting, of the Integrus INT-TXO the frontpanel LEDs light up shortly from green to orange, showing an incorrect state.

Workaround:

This is resolved automatically within 5 seconds, so no action required.

3.4 Demonstrator shows 500 Internal Server error

Issue:

Upon pressing F5 the demonstrator shows a 500 Internal Server error.

Workaround:

Do not use F5 in the demonstrator application as this automatically logs out the user. After pressing F5 (refresh) you need to login again.

3.5 INT-TXO remains in static IP when downgraded to 6.11 (or lower) software

Issue:

Upon pressing downgrading a INT-TXO which has Static IP-addresses configured, the CAP-adaptor remains to have a static IP-address.

Workaround:

Upgrade the INT-TXO to 6.20 or more recent version and set the IP-addressing to DHCP. Then downgrade the INT-TXO again.