

## Hand-Held Multiplex Point Programmer

### Power

*Refer to User Guide (PN 35262) for instructions on using this device.*

ON: Press and hold (1) until beep.

OFF: Press and hold (#) and (\*) until beep.

### Programming

1) "Ad" prompt: Enter the 3-digit address, press (#).

2) "bus" prompt: Press (1) for Busloc or (3) for no Busloc.

If Busloc is chosen, enter 5-digit Busloc code at "cod" prompt.

Press (#).

3) "LTP" prompt: Enter point type (see table below). Press (#).

4) Press (#) to program a point, or (1) to program the D8125MUX only.

NOTE: Press (\*) at any time to backup through the sequence.

### Entering Interrogation Mode

Press and hold (7) and (9).

Decimal Value	Point Type
1	Contact (or Single Point Module)
2	Sensor
3	I/O Module
4	MUX Smoke Detector w/o Low Temp
5	MUX Smoke Detector with Low Temp
6	Dual Point

PN 35264B