


ITS-ALINK-PLUS WINDOWS BASE A-Link Plus



ITS-ALINK-PLUS software is the remote programming software for compatible control panels. It provides a flexible and user-friendly interface between a PC and control panels. With this software, the control panels can be programmed remotely through a modem, or directly from the PC using the Direct Link cable. Use this software to manage customer information, program customer control panels, and remotely connect to, and operate, control panels. It is easy to upload and download programming information between the control panel and the PC, obtain a visual representation of current system status, arm or disarm the system, operate various programmable outputs, and obtain reports of control panel data and journal logs. The transfer tool transfers data from older versions of A-LINK software to the ITS-ALINK-PLUS software.

Functions

Remote Operation

Once a valid connection is established between the PC and control panel, operators with appropriate security levels can:

- · arm or disarm the system
- · turn sirens on or off
- turn various programmable outputs on or off

Report Capability

The last 40 events in the control panel can be displayed and printed for a hardcopy record.

Three Programmable Security Levels

The system administrator (Administrator Level) can enable or disable certain ITS-ALINK-PLUS software functions for each operator by assigning a required

- ▶ View and update compatible control panel data
- ► Send and receive programming data between the A-Link Plus computer and the control panel
- ► Remotely arm or disarm the control panel and outputs control
- ► View control panel event history
- ► Multi-lingual user interface

security level to each function and a security level to each operator. Operators can only perform functions for which they have a valid security level.

The available security levels are:

- Administrator Level: allows full access to all system configurations
- Operator Level: allows full access to all system configurations except print and user settings
- Registrar Level: allows entry of customer information only

Installation/configuration notes

Compatibility Information

The ITS-ALINK-PLUS software supports the following control panels:

- ICP-CMS6-CHI v1.0 (and higher)
- ICP-CMS8-CHI v1.0 (and higher)
- ICP-CMS40-CHI v1.0
- ICP-AMAX-P-EN
- ICP-AMAX-PCB-EN
- ICP-AMAX-P
- ICP-CC404 v1.x
- ICP-CC408 v1.x
- ICP-CC488 v1.x
- Solution 16 (CC880 and SC8016) v2.x and later
- Solution 16 (CC880)(Solution 16 v1.4)
- Solution 844 (CC404 v1.x and CC404 v2.x)
- Solution 862 (CC406 v1.x)
- Solution 880 (CC408 v1.x and CC408 v2.x)
- Solution Ultima 844 (CC484 v1.x)
- Solution Ultima 862 (CC486 v1.x)
- Solution Ultima 880 (CC488 v1.x and CC488 v2.x)

- Solution 2000
- Solution 3000
- Solution 4000
- 5500 series
- 8500 series

Parts included

Quantity	Component
3	User guide

Technical specifications

System requirements

Operating system	Windows 10 (32 bit); Windows 10 (64 bit)
Processor type	Intel core i3
Processor speed	1.4 GHz
Memory (RAM) (GB)	4 GB
Free space (GB)	20 GB

Ordering information

ITS-ALINK-PLUS WINDOWS BASE A-Link Plus

Windows-based remote programming software for compatible control panels

Order number ITS-ALINK-PLUS | F.01U.164.995

Represented by:

Europe, Middle East, Africa: Bosch Security Systems B.V. P.O. Box 80002 5600 JB Eindhoven, The Netherlands www.boschsecurity.com/xc/en/contact/ www.boschsecurity.com

Germany:
Bosch Sicherheitssysteme GmbH
Robert-Bosch-Platz 1
D-70839 Gerlingen
www.boschsecurity.com

North America: Bosch Security Systems, LLC 130 Perinton Parkway Fairport, New York, 14450, USA www.boschsecurity.com Asia-Pacific:
Robert Bosch (SEA) Pte Ltd, Security Systems
11 Bishan Street 21
Singapore 573943
www.boschsecurity.com/xc/en/contact/
www.boschsecurity.com/