




1 |




2 |




3 |




4 |




5 |




6 |






7 |



8 |





<https://commerce.boschsecurity.com/gb/en/Horn-loudspeaker-30W-music/p/F.01U.169.386/>



**EN 54-24 DoP  
Datasheet**

**Music horn loudspeaker, 30 W**  
LH1-UC30E



en Quick installation guide

**Bosch Security Systems B.V.**  
Torenallee 49  
5617 BA Eindhoven  
Netherlands  
[www.boschsecurity.com](http://www.boschsecurity.com)  
© Bosch Security Systems B.V., 2024



1438

Bosch Security Systems BV  
Torenallee 49, 5617 BA Eindhoven, the Netherlands  
13  
1438-CPR-0252

EN 54-24:2008

Loudspeaker for voice alarm systems  
for fire detection and fire alarm systems for buildings  
Music Horn Loudspeaker 30 W  
LH1-UC30E  
Type B  
DoP: LP062922v1