

Installation notes

For a correct installation of the full program, please follow these steps:

- Unzip the zip-file to a location on your local hard drive. Do not run the installation from within the zip-file!
- Run the installation by double clicking on the file EASEAddressSetup.exe. Do NOT run the installation from the file EASEAddressSetup.msi!

If you do not follow these steps, EASE Address might ask for the folder with System Definitions, when the program is started. If you face that issue, follow these steps:

- Copy the 'Data' folder in the installation package to your hard drive. This folder contains all System Definitions, which are all Bosch speaker types in .gll format.
- Select this folder on your hard drive, when EASE Address asks for a folder with System Definitions.