

Prosound Ceiling Speakers

LC2-PC30G6-4 | LC2-PC30G6-8 | LC2-PC30G6-8L |
LC2-PC60G6-8H | LC2-PC60G6-10



Table of contents

1	Safety	4
2	Welcome	5
2.1	<i>Important Features</i>	5
3	System overview	6
3.1	<i>Model Summary</i>	6
3.2	<i>Packing List</i>	7
3.3	<i>Product Feature Identification</i>	7
4	Installation and Wiring	9
4.1	<i>Step 1 – Cut the Hole</i>	9
4.2	<i>Step 2 – Install C-Ring and/or Tile Rails</i>	9
4.3	<i>Step 3 – Attach Wiring to the Ceramic Connector</i>	10
4.4	<i>Step 4 – Mount the Speaker into the Ceiling</i>	11
4.5	<i>Step 5 – Connect an Auxiliary Support Line</i>	11
4.6	<i>Step 6 – Adjust Tap Selector</i>	12
4.7	<i>Step 7 – Attach the Grille</i>	13
5	Troubleshooting	14
6	Technical data	15
7	Appendices	18
7.1	<i>Appendix A Painting the Speaker</i>	18

1 Safety

Safety First

Suspending any object is potentially dangerous and should only be attempted by individuals who have a thorough knowledge of the techniques and regulations of rigging objects overhead. Bosch strongly recommends that all speakers be suspended taking into account all current national, federal, state and local regulations. It is the responsibility of the installer to ensure that all speakers are safely installed in accordance with all such regulations. When speakers are suspended, Bosch strongly recommends that the system be inspected at least once a year. If any sign of weakness or damage is detected, remedial action should be taken immediately. The user is responsible for making sure that the supporting surfaces, and any additional hardware used, is capable of supporting the loudspeaker. Any hardware used to suspend a loudspeaker array that is not provided by/ associated with Bosch is the responsibility of others.

Safety point

As an added safety measure, it is strongly recommended to utilize a properly rated secondary safety cable (provided by the installer) to securely fasten the speaker from the safety point on its back to a secondary mounting structure on the building.



Caution!

The seismic tab (auxiliary support ring) is not intended for primary suspension of the loudspeaker. The seismic tab should only be used as a secondary safety point.



Caution!

Ceiling mount speaker's safety cable

The safety cable should be installed with 1-3 inches (25.4-76.2 mm) of slack.

2 Welcome

Thank you for purchasing Bosch loudspeakers. Read through this manual to familiarize yourself with features, applications, and precautions before you use these products. Bosch loudspeakers use innovative design and materials to provide premium-level performance in a flush-mount ceiling format. Four models comprise by Bosch: the LC2-PC30G6-4 with a 4-inch LF driver and a .75-inch, titanium-coated tweeter with waveguide; the LC2-PC30G6-8 with an 8-inch LF driver and a 1-inch titanium-coated tweeter with waveguide; the LC2-PC60G-8H with a fully waveguide-loaded 8-inch LF driver and a 1-inch titanium coated tweeter; and the LC2-PC60G6-10 , a true ceiling-mounted subwoofer designed to augment and extend the full-range model's low-frequency response.

2.1 Important Features

- Model for model, has superior performance to competing brands
- Comes with both 70V/100V or 8-ohm operation standard on every model
- Includes all installation accessories commonly needed for most jobs
- Designed for use in voice alarm systems

3 System overview

3.1 Model Summary

LC2-PC30G6-4

Perfect for conventional rooms. It has excellent bandwidth in an esthetically very unobtrusive installation profile. Its compact design fits in tight areas. Its 4-inch woofer and waveguide-coupled, titanium-coated dome tweeter give smooth, wide frequency response. The enclosure is ported and tuned to provide surprising bass response in such a compact package. Features an easy 3-point mounting system for quick installations.

LC2-PC30G6-8

The LC2-PC30G6-8 has a specially tuned enclosure and 8-inch woofer to provide amazing bass response. The 1-inch waveguide-coupled tweeter gives smooth controlled coverage out to 20 kHz. Perfect for installations where a flush-mount design is desired but demand for high-quality audio exists. Features a 4-point mounting system to make installations fast and easy.

LC2-PC30G6-8L

The LC2-PC30G6-8L is the same as the LC2-PC30G6-8 but in a low-profile installation package. Ideal for tight ceiling spaces.

LC2-PC60G-8H

The LC2-PC60G-8H is ideal for high ceilings and reverberant “problem” rooms. Its exclusive ported, waveguide-coupled, 8-inch driver provides excellent intelligibility and definition. The 8.2HC’s patent pending design provides great coverage control throughout the voice range and above. No other ceiling speaker system provides the combination of excellent pattern control, wide bandwidth, high power handling, and compact design like the LC2-PC60G-8H.

LC2-PC60G6-10

The LC2-PC60G6-10 packs a 10-inch subwoofer in a tuned high performance enclosure to give amazing low frequency performance down to 45 Hz! It is one of the few quick-mount ceiling TRUE subwoofers available. Flexible installation and powerful low-end performance make it the ideal mate to any Bosch ceiling model.

3.2 Packing List

Item	Quantity	Part
A	2	Speaker system
B	4	Tile rails
C	2	C-ring support
D	2	Grille
E	1	Owner's manual
F	4	Support ring screws
G	1	Cutout template
H	2	Paint shield




Figure 3.1: Packing list

3.3 Product Feature Identification




Figure 3.2: Bottom of speaker




Figure 3.3: Top of speaker

Item	Description
1	Steel back can
2	Mounting screws
3	Tap selector
4	Grille safety tether hole
5	Rotating mounting tabs
6	Ceramic connector
7	Seismic tab (auxiliary support ring)
8	Grille safety tether

Bosch Ceiling Series Systems (sold in pairs)

Model Part No	Description
LC2-PC30G6-4	4" coaxial speaker with horn-loaded, Ti-coated tweeter
LC2-PC30G6-8	8" coaxial speaker with horn-loaded, Ti-coated tweeter
LC2-PC30G6-8L	Same as C8.2 above except with low-profile backcan
LC2-PC60G-8H	8" waveguide-coupled coaxial speaker with horn-loaded, Ti-coated tweeter
LC2-PC60G6-10	10" High performance subwoofer

4 Installation and Wiring

The Bosch mounting system has been designed so that, if necessary, the installation can be done from beneath the ceiling. In some cases with a suspended ceiling grid, however, it may be easier to access from both the top and bottom of the ceiling tile during the installation process. Typical installation hardware needed for either suspended ceilings or sheetrock ceilings is included. The ceiling speaker assembly is held in place by mounting tabs that securely grip the ceiling material. Input wiring is attached to a removable terminal block connector that can be prewired if necessary before speaker installation to speed up the installation process.

4.1 Step 1 – Cut the Hole

For suspended tile or sheetrock ceilings, cut out the hole either by tracing the cardboard template or with a circular cutter set to the appropriate cutout size. If the wire has been pre-installed, pull the wiring through the cutout hole.




Figure 4.1: Cut ceiling hole

4.2 Step 2 – Install C-Ring and/or Tile Rails

All Bosch speakers come packaged with two types of backing hardware: a C-ring and two tile rails. For suspended ceiling installations, insert the C-ring through the hole cut in the ceiling tile. Place the C-ring around the hole with the tabs located as shown. Insert the tile rails through the cut hole in the ceiling tile. Snap the two rails into the two tabs in the C-ring and align the rails so that the ends extend OVER the T-channel grid on the side of the tile. Secure the rails onto the C-ring tabs by inserting a screw through each tab into the rail, as shown.




Figure 4.2: Secure rails to C-Ring

INSTALLATION NOTE: TILE RAILS AND C-RING

Each speaker comes with two tile rails which are designed to fit either standard 24-inch-wide or 600-mm-wide tiles. It is important to note that the tile rail pieces do not actually attach to the T-grid struts. The ends of the rails sit OVER the T-grid strut. Normally, the tile supports the rails. The tile rails are pre-punched at regular intervals with holes along their length. This allows the C-ring to be positioned at any point along the rail. If the tile comes out or falls apart, the ends of the support rails fall onto the T-grid, which prevents the speaker assembly from falling.

Always use all included support hardware when installing into suspended ceiling tiles to make sure the installation is secure.

For sheetrock ceiling installations, the C-ring should be used by itself to reinforce the ceiling material and to spread out the pressure from the speaker hold-down tabs. Guide the C-ring through the cut hole in the ceiling, and place it on the back side of the hole before inserting the speaker.

4.3 Step 3 – Attach Wiring to the Ceramic Connector

Insert the bare end of wire into the appropriate connector terminals as described below and screw down the hold-down screw until tight, using a small screwdriver.





Figure 4.3: Tighten with screwdriver

When adding a subwoofer, be sure to observe the correct polarity. The LC2-PC60G6-10 subwoofer has been designed for optimum performance when used with the LC2-PC30G6-4. In order to maximize the low frequency output when used with the LC2-PC30G6-8, LC2-PC30G6-8L or LC2-PC60G-8H, the polarity of the LC2-PC60G6-10 subwoofer should be reversed.



LC2-PC60G6-10 Subwoofer LC2-PC30G6-4 Loudspeaker

Figure 4.4: Subwoofer polarity with LC2-PC30G6-4




Figure 4.5: Subwoofer polarity with LC2-PC30G6-8/LC2-PC60G6-8H/LC2-PC30G6-8L

4.4 Step 4 – Mount the Speaker into the Ceiling

Push the speaker into the ceiling hole until the front baffle rim is flush with the ceiling. Tighten the mounting tabs by turning the screw clockwise until the speaker is secure. Please note that the first clockwise quarter-turn rotates the attachment tabs outward. The remaining turns tighten the tabs down onto the back of the ceiling surface.




Figure 4.6: Mount speaker into ceiling




Figure 4.7: Tighten mounting tabs

4.5 Step 5 – Connect an Auxiliary Support Line

As an added safety measure, it is strongly recommended to utilize a properly rated secondary safety cable (provided by the installer) to securely fasten the speaker from the safety point on its back to a secondary mounting structure on the building.



Caution!

The safety point (auxiliary support ring) is not intended for primary suspension of the loudspeaker. The safety point should only be used as a secondary safety point.

Note the support ring on the back of the speaker. The ring allows for connection to a independent and secure anchor point. Construction codes often require the use of this secondary support point.



Caution!

Ceiling mount speaker's safety cable

The safety cable should be installed with 1-3 inches (25.4-76.2 mm) of slack.




Figure 4.8: Attach auxiliary support

4.6

Step 6 – Adjust Tap Selector

The tap selector switch is located on the front baffle. Adjust the speaker to the appropriate tap setting before installing the grille. In some 70V/100V constant voltage installations it is advisable to leave the grilles off if final speaker audio level balance adjustments are to be made later. After the levels are adjusted the grilles can then be installed.




Figure 4.9: Adjust tap selector (left: LC2-PC30G6-4/LC2-PC30G6-8/LC2-PC30G6-8L; right: LC2-PC60G6-10/LC2-PC60G-8H)

LC2-PC30G6-4, LC2-PC30G6-8, and LC2-PC30G6-8L

In addition to the 8-ohm setting, the power taps are 30 W, 15 W, 7.5 W, and 3.7 W at both 70.7V and 100V, with a 1.8 W tap for 70.7V only.

LC2-PC60G-8H and LC2-PC60G6-10

In addition to the 8-ohm setting, the power taps are 60 W, 30 W, and 15 W at both 70.7V and 100V, with a 7.5 W tap for 70.7V only.

4.7 Step 7 – Attach the Grille

INSTALLATION NOTE: GRILLE SAFETY FEATURE

Bosch grilles features a unique safety tether to prevent the grille from falling if the grille is removed or comes loose after installation.

First, install the grille’s safety tether by pushing the grille fastener into the hole in the front of the baffle. Second, press the grille into place until the front of the grille is flush with the rim of the baffle. Make sure the grille is securely seated to prevent it from vibrating loose. If you need to remove the grille, the easiest way is to insert two bent paper clips or other pointed objects into holes in the grille, then apply slow even pressure to pull down on the grille until that section of the grille comes out slightly. Continue the same procedure around the perimeter of the grille, loosening a portion at a time until the grille is removed.




Figure 4.10: Attach the grille

5 Troubleshooting

Problem	Possible Causes	Action
No output	Amplifier	<p>Ensure the amplifier channel is being fed an input signal (preferably via a signal input indicator on the amplifier).</p> <p>Verify the amplifier channel's volume is turned up.</p> <p>Connect the loudspeaker and cable, which had no output to another amplifier channel, ensuring an input signal is fed to the new amplifier channel. If you then get output, the problem was the amplifier channel. If not, then the problem is either the cable or the loudspeaker.</p>
	Loudspeaker cables(s)	Replace the cable(s) connecting the loudspeaker system and amplifier.
Questionable or intermittent output, such as crackling	Faulty connection	Ensure all cabling for proper connector contact. A bad connection can result in intermittent contact or dramatically increased resistance, which in turn can cause reduces output or noises unrelated to the signal.
	Improper power tap setting	Verify the power tap setting under the loudspeaker grille is appropriate for the installation and amplifier chosen.
Constant noise such as buzzing, hissing, or humming	A faulty electronic device in the signal chain	Loudspeakers cannot generate these sounds by themselves; you may have a faulty electronic device in the signal chain.
	Poor system grounding	Check and correct the system grounding, as required.
Poor low-frequency output	Out-of-polarity hookup between multiple loudspeakers	When two loudspeakers are hooked up out of polarity (out of phase), the low frequencies cancel each other out. Try reversing the polarity of one of the loudspeakers either by turning around a dual-banana plug at the amplifier or by reversing the tip/sleeve leads on the jack. Which ever condition results in greater low-frequency output is the in-polarity condition.

If these suggestions do not solve your problem, contact your nearest dealer or distributor.

6 Technical data

LC2-PC30G6-4 and LC2-PC30G6-8

Specification	LC2-PC30G6-4	LC2-PC30G6-8
Dimensions (depth x diam.)	6.9 in x 8.3 in (176 mm x 211 mm)	10.0 in x 11.8 in (255 mm x 300 mm)
Cutout dimensions (diam.)	7.1 in (180 mm)	10.6 in (269 mm)
Weight	6 lb (2.7 kg)	11 lb (5.0 kg)
Cabinet construction	Steel enclosure and UL94V-0 rated baffle and bezel	
LF transducer	4 in (100 mm) high-compliance driver (weatherized cone)	8 in (205 mm) high-compliance driver (weatherized cone)
HF transducer	0.75 in (19 mm) Ti-coated dome	1 in (25 mm) Ti-coated dome
Mounting system	Integrated 3-point toggle anchors	Integrated 4-point toggle anchors
Available colors	White (paintable)	
Grille construction	Powder-coated steel	
Acoustic design	Ported cabinet, two-way design, internally damped, w/passive crossover	
Frequency response	65 Hz-20 kHz	50 Hz-20 kHz
Rated Impedance	8 Ω	
Power handling (@ 8Ω)	50 W (with overload protection)	75 W (with overload protection)
Coverage pattern	130° conical	110° conical
Sensitivity (SPL 1 W/1 m)	86 dB	91 dB
Input configuration	8Ω; 70V/100V	
70V/100V power taps	1.8 (70V only)/3.7/7.5/15/30 W	
Recommended High-Pass frequency:		
Included accessories	Tile bridge, mounting ring	

LC2-PC30G6-8L and LC2-PC60G-8H

Specification	LC2-PC30G6-8L	LC2-PC60G-8H
Frequency response	50 Hz - 20 kHz	
Sensitivity (SPL 1 W/1 m)	91 dB	93 dB
Coverage pattern	110° conical	75° conical
Power handling (@ 8Ω)	75 W (with overload protection)	
Rated Impedance	8 Ω	
Recommended High-Pass frequency:	55 Hz	55 Hz

Specification	LC2-PC30G6-8L	LC2-PC60G-8H
Input configuration	8Ω; 70V/100V	
70V/100V power taps	1.8 (70V only)/3.7/7.5/15/30 W	7.5 (70V only)/15/30/60 W
LF transducer	8 in (205 mm) high-compliance driver (weatherized cone)	
HF transducer	1 in (25 mm) Ti-coated dome	
Mounting system	Integrated 4-point toggle anchors	
Acoustic design	Ported cabinet, two-way design, internally damped, w/passive crossover	Ported cabinet, waveguide-coupled, two-way design, internally damped, w/passive crossover
Cabinet construction	Steel enclosure and UL94V-0 rated baffle and bezel	
Grille construction	Powder-coated steel	
Color	White (paintable)	
Cutout dimensions (diam.)	10.6 in (269 mm)	12.6 in (320 mm)
Dimensions (depth x diam.)	7.0 in x 11.8 in (190 mm x 300 mm)	11.9 in x 13.8 in (303 mm x 351 mm)
Net weight	11 lb (5.0 kg)	13.2 lb (6.0 kg)
Included accessories	Tile bridge, mounting ring	
Safety agency ratings:	UL 1480 Safe for use in air handling spaces per UL 2043	

LC2-PC60G6-10

Specification	LC2-PC60G6-10
Frequency response	45 Hz - 150 Hz
Sensitivity (SPL 1 W/1 m)	94 dB
Power handling (@ 8Ω)	100 W (with overload protection)
Rated Impedance	8 Ω
Recommended High-Pass frequency:	45 Hz
Input configuration	8Ω; 70V/100V
70V/100V power taps	7.5 (70V only)/15/30/60 W
LF transducer	10 in (260 mm) high-compliance driver (weatherized cone)
Mounting system	Integrated 4-point toggle anchors
Acoustic design	Ported cabinet, internally damped w/passive crossover
Cabinet construction	Steel enclosure and UL94V-0 rated baffle and bezel
Grille construction	Powder-coated steel

Specification	LC2-PC60G6-10
Color	White (paintable)
Cutout dimensions (diam.)	12.6 in (320 mm)
Dimensions (depth x diam.)	11.9 in x 13.8 in (303 mm x 351 mm)
Net weight	15.5 lb (7.0 kg)
Included accessories	Tile bridge, mounting ring
Safety agency ratings:	UL 1480 Safe for use in air handling spaces per UL 2043

7 Appendices

7.1 Appendix A Painting the Speaker

If the speaker is installed in an area where the interior design requires a color match, these speakers are simple to paint. The speakers can accommodate almost any type of latex or oil-based paint. The bezel/rim can be painted before installation or after mounting into the ceiling.

Painting Process

Clean the rim and grille with mineral spirits or other light solvent. Do not use harsh solvents such as gasoline, kerosene, acetone, or other chemicals. If you use these cleaners you may permanently damage the enclosure. Also, don't use abrasives products such as sandpaper or steel wool.

Either by rolling or spraying, apply two or more thin coats of paint. If you are spraying, hold the spray can at the angles shown.




Figure 7.1: Spray-painting angles

If you are painting the grille also, you must first remove the internal grille cloth. Spray painting is strongly recommended. If the grille is rolled or brush painted, the grille may become clogged with paint and the sound quality will suffer. After the paint has dried, replace the internal grille cloth.

If you wish to paint the speaker along with the ceiling after installation, insert a plastic or cardboard paint shield into the front of the speaker to mask the drivers and internal baffle, paint the speaker, and then remove the shield. Do not paint the steel back can.

Bosch Security Systems B.V.

Torenallee 49

5617 BA Eindhoven

Netherlands

www.boschsecurity.com

© Bosch Security Systems B.V., 2023

Building solutions for a better life.

202309261444